

Safety Instructions

In the unlikely event of smoke or fire:



1. Isolate the lift truck or remove the lift truck from the facility.



2. Unplug the battery from the lift truck and switch it OFF.



3. Remove the battery from the lift truck.



4. If you see flames, use a Class A, B, or C fire extinguisher. Otherwise just leave the battery disconnected outside.



5. Notify a certified service technician ASAP.